

FIG. 1

Mode	CCHGMD	Input	Constant voltage	Relation between constant voltage and reference voltage Vref
0	0	V_BAT 1	V0	$V0 \times \frac{R2'}{R1'+R2'} = Vref$
1	1		V1	$V1 \times \frac{R2}{R1+R2} = Vref$

($V0 > V1$)

FIG. 2




FIG. 3





FIG. 4A

FIG. 4B




FIG. 5

FIG. 6

Full power Residual : 115% AC power supply : ON




FIG. 7





FIG. 8



F I G. 9